



AR-15 Pistol Grip

Installation Instructions

PART# ARA3200, A.5.20.2440, A.5.40.2440

Thank you for purchasing an ATI product!

Advanced Technology
INTERNATIONAL



Pistol Grip Installation

Point the firearm in a safe direction and place the safety in the "on" position. Next pull back the slide, and carefully inspect the chamber and magazine to be sure the firearm is unloaded.

Step #1

Flip the gun over and locate the bolt inside your current grip stock. Loosen the applied screw and begin removing the grip



Figure 1

Step #2

Continue to remove the grip completely. Be careful to remove the safety selector spring from the grip. Keep both the safety selector spring and grip bolt for later installation.



Figure 2

Step #3

Insert the safety selector spring into ATI AR-15 pistol grip. Now, slide the pistol grip into place.

Note: Be sure the safety selector spring is aligned into the safety selector detent hole before the pistol grip is fully in place.



Figure 3

Step #4

Once you have properly fitted the pistol grip in place, insert the grip bolt and tighten until the pistol grip is tightly secure in place.



Figure 4

Advanced Technology International • Made In the USA • Limited Lifetime Warranty
2733 West Carmen Ave • Milwaukee, WI 53209
Toll Free: 800.925.2522 • Fax: 414.464.3112