


Underspin 40XD



Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	W59-4501	Drag knob	24	W32-9901	Casting Trigger Spring
3	W59-4601	Front Cover	25	W32-9931	Casting Trigger
4	W32-4301	Drag Adjusting Plate	26	W32-2701	Drive Gear
5	W32-4201	Drag Washer Retainer	27	W32-2801	Anti-Reverse Pawl Spring
6	W32-3901	Drag Washer	28	W32-2501	Bushing
7	W32-4101	Key Washer	29	W32-9801	Screw (B)
8	W32-4001	Eared Washer	30	W32-2001	Anti-Reverse Cam Spring
9	W32-3801	Drag Spring Washer	31	W32-2101	Anti-Reverse Cam
10	W32-3701	Line Stopper	32	W32-2401	Screw (C)
11	W58-5701	Rotor	33	W32-2201	Anti-Reverse Pawl
12	W59-4701	Spool	34	W32-1601	Anti-Reverse Lever
13	W32-9401	Washer (A)	35	W32-1501	Screw (D)
14	W32-3501	Main Shaft	36	W32-9951	Screw (E)
15	W32-2511	Bail Bearing	37	W32-9971	Side Cover
16	W32-3301	Pinion Gear	38	W32-5001	Washer (B)
17	W32-3201	Main Shaft Spring	39	W32-4701	Handle Metal
19	W59-4801	Cap	40	W59-5001	Handle Stand
20	W59-4901	Side Ring	41	W59-5101	Handle
21	W32-9701	Body	42	W32-5001	Washer (C)
22	W32-9801	Screw (A)	43	W32-5101	Handle Screw
23	W32-2501	Bushing			