# **Guard Dog Security** 100% Satisfaction Policy

Guidance / Satisfaction / Trust < Guaranteet



Bought a Guard Dog Security product and wish you purchased another color instead? Another size? Different function and features? Worry not, Guard Dog's 100% Satisfaction Policy ensures that you will be satisfied with your ultimate self defense product choice, or we will exchange it until you are!

Guard Dog Security believes that you deserve to make the decision you're happy with when it comes to personal security and we would love to work with you during this process. Whether you would like professional product advice, guidance or help. contact us and we will help you.

Did you receive a gift and want to explore our other products? Contact us and we'll swap out your item to your complete satisfaction.

> Guard Dog Security is committed to your security and satisfaction; it is our top priority



Guard Dog Security, Your best friend in security.

Contact us Mon - Fri, 9am - 5pm EST Email, info@quarddog-security.com 📑



- Always out Safety Switch back in the Bottom/OFF position when not in use.
- Never place this device face down when light is on. Doing so could burn/ignite surfaces and causes serious property damage. Always turn LED light off when not in use.

HORNET

- To prevent serious damage to evesight, never look into LED light when light is on.
- Do not touch lens of LED light when light is on or if it was recently on. The lens will be hot and could cause serious burns
- Do not allow children to handle or operate this device.
- Do not use this product for other than its intended use
- Do not charge or operate in close proximity of combustible or flammable materials.
- Do not attempt to charge or operate this device if the cord, plug, battery, bulb, or any part of the LED light is damaged or corroded
- Do not meddle with the bulb, probes, or attempt to touch bulb.
- Avoid direct contact with the head with this device.
- Do not use an outdoor AC outlet to recharge battery.
- Only use charging devices that are provided with this device or its authorized replacements
- Do not disassemble or attempt to alter this device.
- Do not disassemble or tamper with the battery.
- Do not submerge the device, any internal components or any other parts/accessories that come with the device in water or allow moisture to enter.
- Do not dispose of battery. Contact your local county solid waste authority for proper recycling or disposal information
- Do not use the device on metal surfaces, as it may cause electrical voltage to travel on the surface
- Keep away from extreme temperatures and weather conditions.

Note: Failure to comply with the above will void the Guard Dog Lifetime Warranty.

It is recommended to keep this device equipped at all times. It is the buyer's responsibility to check local and state laws for the use of the device.



YOUR BEST FRIEND IN SECURITY

Guard Dog Security is a registered trademark of Skyline USA, Incorporated 4180 St. Johns Parkway, Sanford, FL 32771 USA





Built-in 3 LED Flashlight























## NUMERICAL REPRESENTATION

- OF ► SAFETY SWITCH
  - Bottom: All functions OFF
  - Top: Stun Gun and LED light mode
- **O2** ► ACTIVATOR INDICATOR
- **DE** ► LED FLASHLIGHT ACTIVATOR
- 04 STUN GUN ACTIVATOR
- OB ► STUN GUN PRONGS

- OG ► LED FLASHLIGHT
- CHARGER PRONGS
  - Flips in and out of the bottom of device
- 08 ► LED CHARGING INDICATOR
- O9 ► KEYRING
- 10 ► NYLON HOLSTER

# DEVICE SPECIFICATION

- ► FLASHLIGHT FUNCTION
  - LED Flashlight
- ► PRODUCT WEIGHT
  - 0.625 oz

- ► DIMENSIONS
  - Length: 4"
  - Width: 1.25"
  - height: 0.625"

# How To Use Device

### THIS DEVICE MUST BE CHARGED 4-8 HOURS BEFORE INITIAL USE.

### Charging your device.

To charge this device, make sure the Safety Switch is in the bottom/OFF position. Flip out the Charger Prongs, located at the bottom of the device, and directly insert the prongs into a 110 v outlet. A red LED Charging Indicator will appear, and remain red, at the bottom of the device indicating that the device is successfully charging. Typically, charge time should be 4 to 8 hours, but no longer than 10 hours. However, charging time varies based on usage and battery drainage.

Note: Avoid allowing the battery to completely drain before recharging, as this could decrease the life expectancy of the rechargeable battery and device.

Decreasing light power, varying light outputs and slow stunning power will indicate a low battery. A fully charged device will run, on constant flashlight mode, for up to 3 hours. A device which has used minimal flashlight mode can hold a stun gun charge for up to 2-4 months. Run time will vary by usage of stun gun/flashlight combination, frequency of use and other factors. It is recommended to charge the device regularly.

WARNING: Do not attempt to use or power the device while charging, as this could cause damage to the electrical outlet(s) and possibly result in fire. For additional warnings, see back.

WARNING: Do not allow water or moisture to enter inside the product, on or in the charging components and/or inside the charging outlets. For additional warnings, see back.

## To operate the LED flashlight:

Ensure the Safety Switch is in the top/ON position. This will allow the Activator Indicator to turn ON, signaling that the device is active. Press firmly on the Flashlight Activator to operate the LED Flashlight. Depressing the Flashlight Activator will turn the LED Flashlight off.

Note: Move the Safety Switch to the bottom/OFF position when the flashlight is not in use.

#### To operate the Stun Gun:

Move Safety Switch to top/ON position. This will allow the Activator Indicator to turn on. signaling that the device is active. Firmly press and hold the Stun Gun Activator button to initiate the stun. Release the Stun Gun Activator to stop the stun gun spark.

Note: Depressing the Stun Gun Activator or Flashlight Activator button safely turn the device off. To safely turn the device off. move the Safety Switch to the bottom/OFF position.

Shock effect will vary. A quick touch will startle the assailant, accompanied with pain, discomfort, muscular contraction and shock. Contact on an assailant for further periods can cause the assailant to fall, lose balance and/or muscle control, cause mental confusion, muscle spasms and/or disorientation. Results may vary depending on the area on which the assailant is stunned, physical attributes of the assailant and other factors. This device does not cause permanent damage under normal circumstances. The user will not suffer a chargeback when using this device on an assailant.

WARNING: Do not shock an assailant on the head, heart or on an area of any other major organs.

#### GUARD DOG LIFETIME WARRANTY

This Guard Dog product has a lifetime warranty from the date of original purchase. Manufacturer warrants the product to be free from defective material or factory workmanship and agrees to repair or replace such products within normal use. Removal of battery pack, placement in moist/wet areas/surfaces, placement in extreme heat or cold, unintended use.

mishandling, normal wear and tear, product life cycle use and/or self-inflicted damage to the device will void the warranty. See additional instructions, warnings and notices for further operating details. Owner must provide receipt of purchase/ownership from an authorized Guard Dog Security retailer.