


STAR CHAMBER CLEANING TOOL



Assemble scraper and nose on tool.



Extend handle and insert in chamber.



Turn clockwise to scrape fouling in the star chamber area.



Replace scraper with cleaning pad and insert in chamber.



Turn clockwise to pick up loosened fouling.



8-32 threads accommodate a chamber brush (included) for additional cleaning.